



Packr™ User Manual

Technical Specifications

Configuration

1 Panel solar charger with regulated USB output

Power

3.5 Watt photovoltaic unregulated,

3.0 Watt, 5 Volt System regulated

0.6 Amp output

Dimensions

Size: 495.3mm x 381mm x 165mm

Weight: 822.14g (1.82lb)

Cautions and Warnings

- Avoid immersion in water. If water is splashed on the modules, dry them immediately with a dry cloth or towel.
- Avoid splashing water in or around the USB box area. If exposed to water, immediately shake or blow water from the box.
- Do not bend or crease the modules
- Avoid partially shading modules under load to prevent reduction in power.
- Artificially concentrated sunlight (i.e. with a magnifying glass or by other means) shall not be directed onto the modules.
- Do not cut, scratch, or puncture the modules, hinges, or end terminal.
- Do not stand on or walk on the modules or end terminal.
- Do not drop or allow objects to fall onto the modules, hinges, or end terminal.
- Do not attempt to open, or otherwise dismantle the USB box.

Apple™ Product Warning

When charging Apple™ consumer devices (i.e. iPods, iPhones, iPads, etc.), a time-out will occur when the Packr does not receive direct sunlight onto its panels. This will result in an incompatibility message on your Apple™ product. To resume charging, please unplug and re-plug the unit into the Packr.

What Can EnerPlex Packr™ Do?

The EnerPlex Packr™ can charge most devices that are USB enabled, such as smartphones. Below are some examples of average charge times for a variety of electronic

devices.

- Jumpr™ Mini 1,350 mAh battery ~ 4 hours
- Jumpr™ Stack 4,800 mAh battery ~ 4 hours
- iPhone 5- ~ 3 hours
- Samsung Galaxy S4- ~ 4 hours
- iPad Mini- ~ 9 hours
- Kindle Fire HD 7"- ~9 hours

Getting Started

1. Firmly connect the charging cord from the device you are charging into the USB port on the EnerPlex Packr™.
2. Place the unit you are charging in the provided pouches on the Packr™.
3. For best results, position and angle your EnerPlex Packr™ in a location where it will receive maximum exposure to the sun
4. When finished charging, disconnect the charging cord from the USB port.

Other EnerPlex Gear: see the latest at www.goenerplex.com